



**WIL-MAR
PRODUCTS, INC.**

San Jose, CA

www.wilmarproducts.com • E-mail: sales@wilmarproducts.com
Telephone: 408-532-6400 • 1-800-232-2911 FAX: 888-539-0387

ROOFERS' SAW

(SHAKE, SHINGLE & SLATE)

- **Two Models:
Hand and Power Saw**
- **Cuts Nails and Staples Fast**
- **Self Feeding**
- **Cuts on Pull Stroke**
- **Increases Productivity
for Repairs and Reroofing,
which saves time and money**
- **Interchangeable Blade**

The Saw Blade is designed for use with the Hand Saw or the Power Saw Offset Adapter. When the blade in the hand model becomes dull, simply move it over to the Power Saw Offset Adapter for additional useage and order a new blade for your hand model.

HAND SAW:

Consists of a 25" wood handle (SH-100) and a 27" removable saw blade (SB-100). Worn blades may be replaced.



POWER SAW OFFSET ADAPTER (PA-100)

Fits the Milwaukee Sawzall models 6507 and 6508. Provides a full offset of saw blade for parallel flush cutting. Uses the SB-100.

PART NO.	DESCRIPTION
SH-100	Saw Handle
PA-100	Power Saw Offset Adapter
SB-100	Saw Blade (interchangeable with SH-100 or PA-100)