



**WIL-MAR**  
**PRODUCTS, INC.**  
San Jose, CA

www.wilmarproducts.com • E-mail: sales@wilmarproducts.com  
Telephone: 408-532-6400 • 1-800-232-2911 FAX: 888-539-0387

# THE ROOFERS' SAW

(SHAKE, SHINGLE & SLATE)

## FEATURES

- **Two Models:**  
**Hand and Power Saw**
- **Cuts Nails and Staples Fast**
- **Self Feeding**
- **Cuts on Pull Stroke**
- **Increases Productivity  
for Repairs and Reroofing,  
which saves time and money**
- **Interchangeable Blade**

The Saw Blade is designed for use with the Hand Saw or the Power Saw Offset Adapter. When the blade in the hand model becomes dull, simply move it over to the Power Saw Offset Adapter for additional useage and order a new blade for your hand model.

### HAND SAW:



Consists of a 25" wood handle (SH-100) and a 27" removable saw blade (SB-100). Worn blades may be replaced.

### PART NO. DESCRIPTION

SH-100	Saw Handle
PA-100	Power Saw Offset Adapter
SB-100	Saw Blade (interchangeable with SH-100 or PA-100)

### POWER SAW OFFSET ADAPTER (PA-100)


Fits the Milwaukee Sawzall models 6507 and 6508. Provides a full offset of saw blade for parallel flush cutting. Uses the SB-100.



---

## THE ROOFERS' SAW

is used for removing broken shakes, shingles and slate on repairs and reroofing. The thin blade slips under the roofing material to be removed and cuts off the fasteners quickly and cleanly without damage to adjacent material.



The saw comes in two models:

- **HAND SAW**
- **POWER SAW OFFSET ADAPTER**  
Fits the Milwaukee Sawzall models 6507 and 6508



**WIL-MAR**  
**PRODUCTS, INC.**

San Jose, CA